

# VX-8900i Quick Start

IP address: 192.168.2.200

For WEB Management users:

User Name: admin

Password: admin

For Telnet & SSH users:

User Name: blsh

Password: blsh

\*\*\* Default: DHCP is disabled

In-house lab test at least needs one attenuator  
(30dB~40dB)